



## Installation Instructions For Model 8WD1450/8WD1451

**NOTE: Driver and Passenger Seats are Assembled**

**Items Provided:**

**2— 2" x 18" Hinges Used on Driver and Passenger Seat  
16 —#10 Stainless Steel Sheet Metal Screws**



### **DIRECTIONS:**

Mark the flat area on the bottom front edge of seat after placing them in the boat.

Secure the flat hinges on the bottom of the seat by drilling a 1/8" pilot hole for the screws.

Insert #10 screws with PHILLIPS HEAD SCREW DRIVER.

Place seats in boat and mark the holes from the hinge where they will be secured to the boat.

Drill 1/8" pilot holes making sure the area is clear of fuel tanks and electrical lines.

Secure hinges with #10 screws with PHILLIPS HEAD SCREW DRIVER.