

Please read your DryWave™ instructions carefully before using. If you have any questions about how to use the DryWave™, please call 1-800-261-1330. These instructions should be saved for future reference.

Rev 1106

Safety Guidelines for the DryWave and DryWave 100

- ▲ **Dry Wave**—Do not obstruct the air inflow areas (near the bottom of the case), or the holes on the top of the case. At minimum, 24 inches should be left clear to the sides and above the unit.
DryWave 100—The DryWave 100 does not include any airflow holes. Leave a minimum of 18 inches to the sides and above the unit to properly operate.
- ▲ The DryWave™ can become hot to the touch when operating. Do not touch the unit until it has been unplugged and then allowed to fully cool. Always allow the unit to fully cool before touching, moving, or storing.
- ▲ Set the DryWave™ on a flat, level surface during use. Do not use on top of blankets, long carpet, or any other material which may restrict air flow into the case.
- ▲ To protect against the risk of accidental shock, do not use the DryWave™ on wet surfaces or in areas where it may be able to fall into water. Never immerse the DryWave™ or its power cord in water or other liquids.
- ▲ Do not attempt to disassemble the appliance. Contact us at 800-261-1330 if you encounter any problems with the DryWave™.
- ▲ Close adult supervision is necessary when this appliance is used by or near children.
- ▲ This appliance is rated for indoor usage only, and should not be used outdoors. Do not place the DryWave in the direct sunlight.
- ▲ Do not store or use near sources of additional heat, such as heaters or stoves.
- ▲ Do not use the appliance for any use other than those intended by the manufacturer or modify the product in any way.
- ▲ Do not operate the appliance with a damaged power cord or operate it after the appliance malfunctions or has been damaged in any manner.

Instructions For Use:

- ≈ Airflow around the DryWave™ must be unobstructed for proper operation. Do not place items on or next to the DryWave™.
- ≈ In order for the drying process to work properly, the DryWave™ must be used right side up with no obstructions within 24 inches of the sides and top (for example, don't use the DryWave™ in the extreme corner of a room). Choose your location carefully, away from possible fire hazards and obstructions. This is particularly important when the DryWave™ will be left on while unattended. Only use on a flat, level surface. Do not use on top of blankets, long carpet, or any other material, which may restrict airflow into or out of the case.
- ≈ After properly located, plug the cord into a standard household outlet (110-120 volts AC). The cord must be arranged so that it cannot be pulled on by children or tripped over accidentally.
- ≈ The DryWave™ is "on" whenever it is plugged into a power source. There is no external power switch and the DryWave™ is silent while operating. The unit will take several minutes to radiate warmth.

Instructions For Use Continued:

- ≈ After properly located, plug the cord into a standard household outlet (110-120 volts AC). The cord must be arranged so that it cannot be pulled on by children or tripped over accidentally.
- ≈ The DryWave™ is engineered to operate in cooler environments. It should not be used in areas where the temperature exceeds 75 degrees Fahrenheit.
- ≈ The DryWave™ operates at 120 watts and will work effectively in enclosed areas of up to 1,000 cubic feet. The DryWave 100 operates at 20 watts and will work in areas up to 100 cubic feet.
- ≈ The DryWave™ is equipped with a thermal cut-off switch (not included on the DryWave 100) which will allow the unit to cool to normal operating temperature should it overheat for any reason. The switch will automatically reset and turn the unit back on when normal operating temperature has been reached. Stop using the DryWave immediately if you suspect that it is overheating.
- ≈ **In some cases, you might detect a slight odor the first time you use the Dry Wave™ or The DryWave 100. This is a common occurrence for many small heating appliances. Any odor you detect upon first use is harmless and should dissipate after several hours of use.**
- ≈ When you're finished using the Dry Wave™, simply unplug it from the wall outlet. Allow the unit to fully cool before touching, moving, or storing.

HAVE QUESTIONS? WE
HAVE ANSWERS. CALL
800-261-1330.

Maintenance:

- ▲ The DryWave™ requires no maintenance. It should be kept dust free for best operation.

Limited Warranty:

Due to the many variables in humidity, temperature, room design, and ventilation, Ironwood Pacific Outdoors, Inc. (IPO) is unable to warrant the effectiveness of the appliance to prevent mold and mildew in an application.

Ironwood Pacific Outdoors, Inc. (IPO) warrants to the original retail purchaser of this DryWave™ air dryer that it is and shall remain free of defects in materials and workmanship for two years from date of purchase.

Should the purchaser discover a defect and notify IPO during the warranty period, IPO will, at its option, repair or replace the unit at no additional charge, or refund all or part of the customer's original purchase price if the unit was purchased directly from IPO. This limited warranty does not cover damage caused by improper use, disaster, abuse, or modification.

Limited warranty service may be obtained by first calling, writing, or emailing IPO with a description of the problem or perceived defect. IPO may request documentation to understand the nature of the problem or defect. If a defect or problem is confirmed, IPO will, at its sole discretion, replace, repair, and/or authorize the return of the unit to IPO. Returns must be made to the specified address, along with proof of purchase date, and be properly packaged. Unless otherwise authorized, the purchaser must prepay return-shipping charges. IPO does not accept COD shipments.

All express and implied warranties for this product, including the warranties of merchantability and fitness for a particular purpose, are limited in duration to a period of two years from the date of purchase and no warranties, whether expressed or implied, will apply after this period.

If this product is defective, your sole remedy shall be repair, replacement, or refund as provided above. In no event will IPO or any of its officers, employees, or agents be liable to you for any damages, including incidental or consequential damages arising out of the use of or inability to use the product, even if IPO has been advised of the possibility of such damages, or for any claim by another party.

Ironwood Pacific Outdoors, Inc. PO Box 1568 | Lake Oswego, OR 97035 | Ph: 800-261-1330

www.drywave.com | email: sales@ironwoodpacific.com